

CASSETTE TAPE DECK


CT-F2121

KCU, DV, NB, DP


SERVICE MANUAL




DP model



DV model



NB model



SCHEMATIC DIAGRAMS, P.C. BOARD PATTERNS AND PART

SCHEMATIC DIAGRAMS AND MISCELLANEOUS PARTS


A

REC/PB AMPLIFIER Ass'y RWF-043

B

C

D



SWITCHES:

- S₁ : REC/PB SELECTOR SW (REC POSITION)
- S₂ : EQ SW (STD POSITION)
- S₃ : INPUT SELECTOR SW (DIN POSITION)
- S₄ : DOLBY SW (ON POSITION)
- S₅ : BIAS SW (STD POSITION)
- S₆ : SENSING SW
- S₇ : MUTING SW (STOP POSITION)
- S₈ : PAUSE SW (OFF POSITION)
- S₉ : PLAY SW (STOP POSITION)
- S₁₀ : POWER SW (OFF POSITION)
- S₁₁ : MIC JACK SW



- PL₁ : DOLBY INDICATOR LAMP
- PL₂ : METER LAMP
- PL₃, PL₄ : ILLUMINATION LAMP

RESISTORS

IN OHM, 1/4W, ±5% TOLERANCE UNLESS OTHERWISE NOTED K:KΩ M:MΩ

CAPACITORS

IN μF UNLESS OTHERWISE NOTED P:pF




CONTROL Ass'y RWG-049


KCU

6




POWER SUPPLY AND O.S.C. ASSEMBLY (RWR-027)







REC/PB AMPLIFIER ASSEMBLY (RWF-043)









S₁ REC/PB SW (REC POSI-)
 S₂ EQ SW (NOR POSI-)
 S₄ DOLBY SW (ON POSI-)
 S₅ BIAS SW (NOR POSI-)







FUSE BOARD ASSEMBLY

1, KCU
model2, DV, DP
model3, NB
model


INDICATOR ASSEMBLY (RWX-087)



LAMP ASSEMBLY (RWX-052)




[illegible]



PANEL STAY

NOTE:


Parts indicated in green type cannot be supplied.



REAR PANEL

NOTE:

Parts indicated in green type cannot be supplied.



[illegible]

Parts indicated in green type cannot be supplied.

REC/PB amplifier assembly
RWF-043

Bonnet case
RNA-220

Cushion

6 Rear panel
See page 53

Bottom plate

Foot assembly
RXA-477

EXPLODED VIEW TRANSPORT

NOTE:

Parts indicated in green type cannot be supplied.

Tape counter See page 62

Head See page 57

Sensing switch See page 58

PSA-2.6x4

PSA-2.6x6

PSA-3x6

Operating button See page 61

M-2.6x6

Transport shassis
See page 59

Eject bracket See page 62

Play, Muting switch
See page 60

EW-2.5

Spring
RBH-189
Spring
RBH-188

Angle

Cushion

PSA-2.6x10

PSA-2.6x6

Spring
RBH-190

Arm assembly
RXA-430

Spring
RBH-221
Bracket
RXA-421

Idler A
See page 57

EW-2.5

Plate
RXA-490

Cushion

FF Spring
RBH-187

FF Plate
RXA-431

PSA-2.6x6

Spring
RBH-184

EW-4

EW-2.5


PSA-2.6x6
Adjusting screw
RNK-154

Belt
REB-116

Spring
RBH-220


TP-45 Flywheel assembly
RXA-432

Flywheel plate




HEAD


NOTE:
Parts indicated in green type cannot be supplied.



IDLER A

NOTE:
Parts indicated in green type cannot be supplied.







TRANSPORT CHASSIS

NOTE:

Parts indicated in green type cannot be supplied.






OPERATING BUTTON ASSEMBLY (RXA-498)

NOTE:


Part indicated in green type cannot be supplied.



TAPE COUNTER

NOTE:


Parts indicated in green type cannot be supplied.



EJECT BRACKET

NOTE:

Parts indicated in green type cannot be supplied.



CASSETTE TAPE DECK

CT-F2121

NB, DV, DP

<ART-186-0>

Additional

Service Manual

Employ this additional service manual for the units with serial numbers indicated in the table.

For detailed please refer to the Service Manual of CT-F2121/KCU, NB, DV, DP.

Model \ Serial No.	Serial No.
NB	4206301 ~
DV	9425701 ~
DP	9512801 ~

 **PIONEER®**

1. ADJUSTMENTS

1.1 MUTING SWITCH ADJUSTMENT

When PLAY button is pressed, perform adjustment so that configuration shown in Fig. A-1 is obtained after contact 1 in Fig. A separates from contact 2.




Fig. A

1.2 MOTOR SWITCH ADJUSTMENT

Set all FUNCTION buttons to OFF positions. Perform adjustment so that space A shown in Fig. B becomes 0.05 ~ 0.15 mm.





Fig. B

2. EXPLODED VIEW TRANSPORT



NOTE:

Parts indicated in green type cannot be supplied.





Components of section indicated by orange color have been changed.


Transport shassis See page 6



Play, Muting switch See page 7




Sensing switch, Motor See page 8



2.1 TRANSPORT CHASSIS

The parts indicated by designation and part numbers are newly-employed in the NB, DV, DP model.


The parts without description are the same as the parts in the K model.



2.2 PLAY MUTING SWITCH

The parts indicated by designation and part numbers are newly-employed in the NB, DV, DP model.


The parts without description are the same as the parts in the K model.



2.3 SENSING SWITCH MOTOR

The parts indicated by designation and part numbers are newly-employed in the NB, DV, DP model.

The parts without description are the same as the parts in the K model.



PIONEER ELECTRONIC CORPORATION

4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan

U.S. PIONEER ELECTRONICS CORPORATION

75 Oxford Drive, Moonachie, New Jersey 07074, U.S.A.

PIONEER ELECTRONIC (EUROPE) N.V.

Luithagensteenweg no. 9, 2030 Antwerp, Belgium

PIONEER ELECTRONICS AUSTRALIA PTY. LTD.

178-184 Boundary Road, Braeside, Victoria 3195, Australia